


SpacePole Solo™ For Ingenico iSMP4

Installation Guide




MK15-0260 version 1.0 09/2018


Cable routing options




Other cable routing can be used as necessary. No cable shearing/cutting allowed.



#1: Front




#2: Under




#3: DuraTilt™

Ingenico iSMP4 M-Case use

Insert




Remove




SpacePole Solo™ use

1 MultiGrip™ mounting




Inserting Ingenico iSMP4 M-Case

2




Power inlet




Removing Ingenico iSMP4 M-Case


3



SpacePole Solo™ security



Screws are not included.



Get more information at: ergonomic.solutions